


# Anti-Lift Kit

## INSTALLATION INSTRUCTION MANUAL







# Table of Contents

SAFETY.....	3
STEP 1: DETERMINING PLACEMENT OF ANTI-LIFT KITS .....	4
STEP 2: INSTALLING THE POSTS .....	4
STEP 3: INSTALLING THE BRACKETS .....	5

# SAFETY

Read this section carefully before proceeding. The following symbols may appear prior to certain safety related assembly and installation steps described in this manual.

FAILURE TO OPERATE AND INSTALL THIS UNIT AS INSTRUCTED MAY RESULT IN SERIOUS INJURY OR DEATH.



## Step 1: Determining and Placement of Anti-Lift Kits

If the system measures 28 feet or more in length, the installation of two anti-lift brackets on both sides of the trailer (consisting of the 4-inch and 6-inch kits) will be required. If the system is less than 28 feet but greater than 15 feet only the 6-inch kit will be necessary. If the system is less than 15 feet then only the 4-inch kit is necessary.

For systems greater than 28 feet, the 6-inch kit will be connected to the rear most bow in the front third of your trailer. The 4-inch kit will be connected to the bow  $\frac{2}{3}$  of the way down your trailer from the front. See Figure 1.1.




Figure 1.1

For systems less than 28 feet, the 6-inch kit will be connected to the bow that is closest to the center of the trailer. For systems less than 15 feet the 4-inch kit will be connected to the bow closest to the center of the trailer. See Figure 1.2.




Figure 1.2

## Step 2: Installing the Posts

Once you have determined which bow(s) will have the post(s) attached to it, remove the washer and nut from the bolt on the bow end. Slide the anti-lift post over the bolt. Secure the anti-lift post using the same washer and nut.





Figure 2.1




Figure 2.2

### Step 3: Installing the Brackets

Extend the tarp so that the system is in the fully covered position. Position the anti-sail bracket around the posts. Ensure that the mouth of the bracket is facing the front of the trailer. Mark the position of the mounting holes.




Figure 3.1

Drill out the mounting holes using a 9/32" drill bit. Then using the supplied 5/16"-18x1-1/4" thread cutting screws, secure the bracket to the trailer.




Figure 3.2

Run the system in and out a few times to ensure that the anti-lift kits are working properly. Adjust as necessary.